MASKING MADE EASY FOR A VARIETY OF PAINT CHEMISTRIES

PaintMask

PM-50

Tired of your paint mask breaking into tiny shards? ABI Tape has a solution for you: **PaintMask PM-50** resists urethanes and removes cleanly, leaving no residue behind. For easy installation of PM-50, we recommend TransferRite® 592U high tack application tape to get the job done right.



Looking for a transfer tape to complement your PaintMask? We recommend:

TransferRite® ULTRA®

592U: HIGH TACK

- High Tack Paper Application Tape
- Adheres to Exposed Release Liners
- Recommended for Use With PM-50



To learn more about TransferRite products, please visit: **WWW.ABITAPE.COM**

PM-50

- Cuts & Weeds Easily
- Conforms to Compound Curves
- One-Piece, Residue-Free Removal
- Works with Automotive Urethanes
- 3.4mils Thick
- Withstands Bake Cycle Temp of 110°F
- Readily Available in 50 Yard Rolls
- 15" Punched, 30" Punched and 30" Unpunched



